



## HOW TO CHANGE THE HOUR COUNTER OR THE MILAGE COUNTER

1) Select "Settings" in the top menu



2) Highlight the device and then select "Edit"



3) Under Start select “Km start” or “Hours start”

The fields are adding or subtracting the entered value to the current value.

This means that if you want to add 6 hours to the current value, you just type 6 in the field “Hours start”, click save and you’re done!

The screenshot shows a web application interface with a top navigation bar containing 'Map', 'Reports', 'Service', 'SMS', 'Alarms', 'Settings' (highlighted), and 'Support'. Below this is a sub-navigation bar with 'Fleet', 'Categories', 'Clients', 'Groups', 'Users', 'Service schedules', 'Zones', 'POIs', and an 'Edit' button. The main content area is a form for editing a unit. On the left, there is a search field 'Enter unit name or serial number:' and a 'Groups:' dropdown menu. The main form fields include: 'Serial number:' (827704), 'Name:' (827704), 'Reference number:', 'Type' (radio buttons for Car, Machine, Boat), 'Equipment information' (Brand, Type, Year of production, Model), 'Client:', and 'Category:'. At the bottom, the 'Start' section is highlighted with a red box, containing 'Km start:' (0) and 'Hours start:' (0). Below the 'Start' section, the word 'Inputs' is partially visible.